

Replacement Blade Instructions

SCT-7MMQR Replacement Blade Kit

Each replacement blade kit includes the following:

Qty	Description	Application
1	Strip/Core Blade	Cores dielectric foam and strips back aluminum sheath
1	10-32 x ½" Button Head Screw	Installs the SC blade in the "A" housing.*
1	1/8" Short Arm Hex Key	For all button head screw installations.
1	3/32" Short Arm Hex Key	Used to attach T-handle for manual operation.
1	Jacket Strip Blade	For use in "B" housing to peel away jacket from aluminum sheath.
1	10-32 x ¾" Button Head Screw	Acts as a removable stop for feed-through connectors. Use when applicable.
1	10-32 x 5/8" Button Head Screw	Installs JSB blade in "B" housing.
1	U-Bend Spring Washer	For optional use in cases where cable variations cause JSB to come in contact with aluminum sheath. The spring washer stored under the 5/8" screw head may be installed under the JSB.

*Align exit slots on blade to match body.

IMPORTANT NOTE: In order to validate warranty and maintain optimum tool performance, it is necessary to replace *all* of the button head screws each time the blade is replaced.

Ben Hughes Communication Products Company

207 Middlesex Avenue

P.O. Box 373

Chester, CT 06412 USA

Email: toolmaker@cableprep.com Website: www.cableprep.com

Tel: (860) 526-4337 • Fax: (860) 526-2291 • Toll Free: 1-800-394-4046